

MFD28/32 Gen2 Manual



Content

1	Description and scope of delivery5								
2	Cor	Connection of the plugs6							
3	Nav	Navigation on the display							
4	Log	ging		.0					
5	Me	nu na	vigation on the display1	.1					
	5.1	Рор	up1	.2					
	5.2	Can	Bus1	.2					
	5.2	.1	TRI/TRX File 1	.3					
	5.2	.2	Can Speed 1	.3					
	5.2	.3	Can Term 1	.3					
	5.2	.4	Can Filter 1	.3					
	5.2	.5	Protocol 1	.3					
	5.2	.6	Can Switch 1	.3					
	5.2	.7	Timeout 1	.3					
	5.3	Sens	sor Init1	.4					
	5.4	Lice	nse1	.5					
	5.5	Gea	rs1	.5					
	5.6	Spla	sh Screen1	.6					
	5.7	Star	t Page 1	.6					
	5.8	Shift	tlight1	.6					
	5.9	Dim	Sensivity 1	.6					
	5.10	Page	es1	.6					
	5.11	Cust	tom Button1	.8					
	5.12	Dem	no Mode1	.8					
	5.13	Тоо	Soon Junior	.8					
	5.14	Nigh	nt Mode1	.9					
	5.15	Unit	ts 1	.9					
6	The	TRI/1	TRX File	20					
	6.1	Nam	ne encoding of TRI/TRX files	2					
	6.2	Prot	cocols	2					
	6.3	TRI/	/TRX file problem	3					
7	Adj	ust or	۲ the display 2	:5					
8	Flas	shing	the firmware2	27					
Re	ev 1.2			2					

9	Customizing the display on the PC with the DSS29					
	9.1	Conr	nection	30		
	9.2 TRI Editor					
	9.	2.1	Handling	32		
	9.	2.2	Global enhanced mode	34		
	9.3	Page	25	35		
	9.	3.1	predefined pages	37		
	9.	3.2	Widgets	38		
		9.3.2.1	General	39		
		9.3.2.2	Color selection	40		
		9.3.2.3	vertical bar	41		
		9.3.2.4	round meter	42		
		9.3.2.5	YT diagram	43		
		9.3.2.6	Enumeration	44		
		9.3.2.7	Icon	45		
		9.3.2.8	sensor value	46		
		9.3.2.9	Gear	49		
		9.3.2.1	0 G-meter	50		
		9.3.2.1	1 can switch	51		
		9.3.2.1	2 multi switch	52		
		9.3.2.1	3 horizontal bar	54		
		9.3.2.1	4 Needle	55		
		9.3.2.1	5 Overlay	57		
		9.3.2.1	6 Pixel	58		
		9.3.2.1	7 performance meter	59		
		9.3.2.1	8 status rectangle	60		
		9.3.2.1	9 rectangle	61		
		9.3.2.2	0 text field	62		
		9.3.2.2	1 picture	63		
		9.3.2.2	2 RPM bar	63		
	9.4	Log	/iewer	66		
	9.5	Othe	r settings	67		
	9.	5.1	General settings	67		
	9.	5.2	Can Bus	67		
	9.	5.3	Shift light	67		
	9.	5.4	Gears	67		

	9.5.	5	Sensor init	68
	9.5.6		IO pins (Dimming and page switch)	68
	9.5.7		Can Transmit	69
	9.5.8		User tables	70
	9.5.9	Э	Math Channels	70
	9.5.2	10	Boost/PWM Control	71
ç	9.6	Uplo	pad	72
ç	9.7	Can	Log	73
ç	9.8	Wor	k offline	73
10	AIN	Setup	o (analog inputs)	74
11	FAQ	•••••		76
2	L1.1	TRI/	TRX file problem	76
2	L1.2	Disp	lay does not turn on	76
2	L1.3	Disp	lay remains black or white	76
-	L1.4	I dor	n't get any data (no can)	76
-	L1.5	Gear	r indicator does not work	77
-	L1.6	Yello	bw bar at the bottom of the data display	77
-	L1.7	MyF	Performance Meter runs permanently	78
-	L1.8	Mys	shift flash doesn't work	78
2	L1.9	How	do I change my home logo?	78
2	L1.10	How	to get other logos on the pages	78
2	1.11	How	do I rotate the UI of my display?	79
2	L1.12	My [DSS gets stuck on page X	79
2	L1.13	How	can I find the cached images of the DSS	79
2	L1.14	How	can I fine-tune a Can Bus sensor	79
2	L1.15	l can	n no longer edit the sensors on the display	79
-	L1.16	No c	connection with diagnostic tester possible	79
-	L1.17	Micr	oSD card content and recovery	80
2	L1.18	Max	xECU with PQ34/PQ35 drivetrain	80

1 Description and scope of delivery

Thank you for purchasing your MFD28/32 Gen2. With the CANchecked data display, you can display live data from your vehicle while driving, *log sensors* and use many other functions that are presented to you in this manual.

This guide explains how to operate and handle your Gen2 data display. In addition to the connection, setup and navigation, this manual deals specifically with the individual setting and the connection and operation of our "Display Setup Software" (*DSS*).

You received your data display in a vehicle-specific mount or in one of our universal mounts. Depending on your order configuration, the contents of your original packaging may vary. Always included are:

- the quickstartguide
- 2 non reflective covers
- A SD card reader adapter
- CANchecked stickers
- One USB cable
- and **either** two Molex connectors (8 pin and 10 pin) and a choice of different pre-crimped leads and two 1kohm resistors **or** a pre-terminated OBD cable

Your display itself has a capacitive touch screen, two Molex connectors on the back, a MicroUSB port and a slot for a MicroSD card. The MicroSD card is always pre-assembled in your CANchecked data display and described by us with data for your vehicle.

The sensors and page configurations are stored on the microSD card. For faster charging and display, the display also has an internal flash memory. To remove the MicroSD card, after switching off the display, the SD card must be pressed in slightly with a suitable object or fingernail to loosen the latching nose. After pressing in, the MicroSD card springs out (**please proceed carefully so that it does not jump out uncontrollably**).

Terms associated with the data display are shown in italics in this guide for better understanding.

2 Connection of the plugs

To operate your MFD28/32 via the Can bus, only four wires are required:

•	12 volts on-board voltage, ideally ignition plus	-> Pin A5
•	Ground	-> Pin A1
•	Can High (<i>CanH</i>)	-> Pin B2
•	Can Low (<i>CanL</i>)	-> Pin B3

Alternatively, you can replace 12 volts on-board voltage and ground with a USB power supply. For operation **in the vehicle**, **we expressly recommend a connection via 12-volt ignition plus and ground.** The wires of *CanH* and *CanL* are always designed as twisted pairs to minimize interference signals.

Connector A has the Molex number 43025-0800, connector B 43025-1000 and crimps 43030-0001 must be used for both connectors.



PLUG	A1	A2	A3	A4	A5	A6	A7	A8	·	* future
A	GND	5V	AIN4	AIN3	12V	SGND	AIN2	AIN1] App	lication
PLUG	B1	B2	B3	B4	B5	B6	B7	B8	B9	B10
В	RX2*	CANH	CANL	SHIFT	RX	TX2*	LOWSIDE	5V	OGND	TX

Figure 1: MFD28/32 Pinout

Of course, *CanH* and *CanL* are not necessarily necessary for operation. Via the four analog inputs (*AINs* – analog inputs) you can also feed the 0-5 volt voltages of analog sensors into the display and have them converted by the display and displayed on it.

By default, our AINs are preconfigured for different sensors:

AIN1: Oil Temperature (OilT)	-> Pin A8
AIN2: Exhaust gas temperature (EGT)	-> Pin A7
AIN3: Oil pressure (OilP)	-> Pin A4
AIN4: Boost pressure (MAP)	-> Pin A3
	AIN1: Oil Temperature (OilT) AIN2: Exhaust gas temperature (EGT) AIN3: Oil pressure (OilP) AIN4: Boost pressure (MAP)

The power supply for operating the analog sensors can also be realized directly via the display. Pin A2 and pin B8 are 5V during operation, and the sensor ground can be obtained from SensorGround A6. The maximum current of 0.5 amperes should not be exceeded.

Furthermore, the MFD28/32 Gen2 has a frequency input (max. 65kHz). With this you can separately feed wheel, engine or turbocharger speed (5V square wave signal) or the ethanol content of your fuel into the display. Pin B5 or B10 can be used for these applications. More information can be found *9.5.6*.

Some settings can be implemented directly via the display. For detailed configuration or the creation of your own pages, the use of *DSS* (Display Setup Software) is necessary. The download is free of charge at https://www.canchecked.de/downloads-category/dss-display-setup-software/. The display is connected via the supplied USB cable. We recommend leaving it connected to the display and hiding the USB plug in an easily accessible place. In this way, easy access to your data display is possible at any time without disassembly. The glove compartment, the side covers of the dashboard, or the trim of the central consoles have established themselves here.

In the meantime, we have produced illustrated installation instructions for numerous vehicles. These can be found on our website under <u>www.canchecked.de/help/einbauanleitungen/</u>. If you have a CANchecked data display with a plug-and-play OBD data cable, it is recommended to connect it briefly with the data display to the OBD socket before final installation behind the fairing in order to check the correct connection and familiarize yourself with the user interface.

3 Navigation on the display

You can operate your display like any standard smartphone with touch and swipe gestures.



Figure 2: Gestures to operate the data display

To switch sides, simply swipe left (one side forward) or right (one side back) across the display.

During the page change, you will be shown in yellow in a cutscene which page you are on. If you switch to a blank page, the display in yellow font on a black background Page *is empty*! indicate.



Figure 3Appearance of a blank page

When delivered, most vehicles come with six pages pre-installed on your data display. In total, you can set up up to ten pages on your display as you like or use our *predefined pages* with the help of the *DSS* and get inspired, more about this in chapter 9.3.1

If you swipe down from top to bottom on your display (red arrow) you will be taken to the *setup* and *DTC* (not available on all vehicles and protocols, more on this in chapter 6.2).

In the setup you can make all settings relevant for the operation of the display. The menu navigation in *the setup* is described in chapter5



Figure 4: Setup and Quick Access Bar

If you swipe your finger from bottom to top (purple arrow) you open the *quick access bar*. These can be accessed from any of the ten pages. Here you will find the button for logging, the slider for the brightness of the display and a configurable *custom button*.

4 Logging

To start and stop the *log*, press the button in the lower left corner after swiping up. Depending on the active protocol (see chapter 6.26.2(without protocol) all *sensors* available in the *TRI/TRX file* are logged.

The *logs* are numerically incremented, and the button appears in green when the *log* is active. If you press the green button again, the *log* will end. The display counts the logs up to 255 and then starts again at 0. This number is not customizable. The number of the active *log* is displayed in the lower left corner, after three seconds the number turns into a small green status icon as long as the *log* is active. The **display only logs when the bar is pushed down**, if the bar is still pushed up the display does not log! Pushing the bar up interrupts the log.

On the SD card in the folder *logs* you will find the log files after successful logging. Alternatively, you can use the *Log Viewer* in the *DSS* to access your logs or delete them from the SD card. The logs are recorded every 62 ms (~16 Hz) and should not exceed one hour due to the overview. You can read more about this in chapter 9.4

The slider for activating and deactivating permanent logging can be found in the Sensor Init (compare chapter 5.3).



Figure 5: Button to start and stop the log

5 Menu navigation on the display

This chapter describes the menu navigation and the submenus of the *setup*. Each point of the *setup* is processed in a subchapter. The setup can always be terminated by clicking on the white $\frac{1}{2}$ on a red background.

SE	TUP	×
Popup	1s	
Can Bus		\rightarrow
Sensor Init		>
License		>
Gears		\rightarrow

Figure 6: Setup

In the submenus you get back to the setup by pressing "<".

	< Gears	too slow 🕺	
6	Gear 1	125	T
Ē	Gear 2	72	
Ξ	Gear 3	50	
k	Gear 4	40	
	Gear 5	32	T

Figure 7: Screenshot from the menu

5.1 Popup

Your data display has the possibility to show you a blue or red *popup* when falling below or exceeding set *min*imal and maximal values.



Figure 8: Red popup when exhaust gas temperature is too high

By default, the *pop-ups* are disabled both in the display and for each *sensor* individually. To activate the *popup*, it must be switched on globally in the setup under the menu item described here (see Figure 6) **and** the *min*imal or *max*imal values and the *popup* for the corresponding *sensor* must be activated in the *TRI file*9.2

In addition to switching the popup on and off, you can also set the length of time the *popup* remains on the screen by tapping the number of seconds. Dwell times of zero to five seconds are possible.

ATTENTION: Depending on the protocol used (OBD, TP2, UDS, BMWE, BMWF), the display only queries the sensors queried on the current page. If, for example, a *popup* for the exhaust gas temperature is created, but this is not queried on the opened page you will get no *popup*!

Alternatively, you can use the *DSS* to *create* the *pixel widget*, which is invisible but adds a virtual sensor to the current view, allowing the popup and logging in. More about this in chapter 9.3.2.16.

5.2 Can Bus

In the Can Bus menu, you will see the status of your data connection at the top right. If the connection is successful there is Can ok, if the connection is not successful there is no Can.

In some protocols and firmwares, there is a lock in front of the submenus. Here, the settings are fixed in the firmware to exclude incorrect operation by the user. In this case, these settings can only be adjusted via the *DSS*.

5.2.1 TRI/TRX File

Under the submenu item TRI/TRX File you can select the *TRI/TRX* File you need from a list or scan your engine data (UDS only) if your engine code letter (MKB) is not yet in the list to start a service request under info@canchecked.de. Depending on which firmware is installed on your display, you may only find *TRI/TRX* files that start with S-XXX, T-XXX, U-XXX or O-XXX. If you want to see other TRI/TRX files you have to flash the appropriate firmware. More information can be found in chapter 6.2

5.2.2 Can Speed

In this sub-item you can set the speed of your Can bus by clicking on the number. Our data display currently supports the following speeds of 125, 250, 500 and 1000 kbit/s.

5.2.3 Can Term

This slider can be used to activate or deactivate a 120 Ohm Can Bus terminator.

5.2.4 Can Filter

By clicking on this submenu, various can *filters* (OBD or vehicle-specific) can be activated or deactivated.

5.2.5 Protocol

With active *protocols*, there is a slider in the menu here to switch the *protocol* on or off, thus locking or unlocking the OBD socket. Deactivating the protocol may be necessary, for example, to access the ECUs via a diagnostic tool. For later operation of the data display, however, the protocol must then be reactivated thus the OBD socket must be blocked again.

5.2.6 Can Switch

Your Gen2 data display can not only receive Can Bus data, but also send it. These can be:

- Touch Button Status (on/off, e.g., to activate Launch Control, ALS or a fan)
- Forwarding of the 4 analog inputs or the digital inputs to the control unit
- Converting Can Bus messages to other addresses

In the Can *Switch* submenu, a selection of Can Switches can be made by clicking on the setting. The following settings are currently offered:

- Off (no Can Switches activated)
- Custom (Can switches can be configured via DSS 9.5.7)
- EMU v3
- LinkECU
- MaxxECU
- Motec

With the preconfigured Can *Switches*, the data display emulates the manufacturer specific Can Switch boards (Ecumaster) or ready-made messages, which can be found in our specific instructions for the ECUs.

5.2.7 Timeout

In the *Timeout* submenu, the length of the *timeout* until the next data query for logs can be set by tapping on the number. By default, this is two milliseconds. The time can be set in increments from two to 20.

5.3 Sensor Init

In the Sensor Init submenu, individual sensors are assigned to essential functions of the data display .

For assignment, the corresponding *sensor* must be clicked on and can then be selected from the list of available *sensors* by clicking on it. The successful dialing is indicated by a **green** box. The *sensor init* can always be terminated by clicking on the white $\frac{1}{2}$ on a red background (changes are saved automatically). By pressing < you get from the submenu back to the *sensor init*.

The essential functions and their default values in the sensor init are shown in Table1.

Essential function	Needed for	Default value
RPM	Gear calculation und Shiftlight	RPM
Speed	Gear calculation	Speed
Page Switch	Changing thesettings by aCan message with a status of 1-10	N/A
Dim Display	Dimming of the Display by a Can message	N/A
Haldex Ext	Setting the Haldex widget	N/A
Gear	Sensor in TRI/TRX File for Gearwidget	Gear
Gear Mode	Sensor in TRI/TRX File for	Automatic: Gear Mode
	Gearwidget	Manual: N/A

Tabla1.	Facontial	functions	:	the	Concor	In it
TUDIET.	Essentiur	junctions	Ш	uie	Selisol	ΠΠL



Figure 9: Sensor Init

In addition to the settings of the essential *sensors*, the *Sensor Init* also contains Flash *usage* and *Reboot gauge*. Behind the words *Flash usage* is the current percentage utilization of the flash memory in parentheses. As well as behind it the button to erase the flash memory.

Attention: if you delete the flash memory, all images from the SD card are initially loaded into the flash memory the next time the data display is restarted. The start animation of the display jerks and the **first loading** of the pages can be a bit slower.

By clicking on the *lettering Reboot gauge*, a restart of the data display is forced without disconnecting the power supply.

In the last item of the sensor init you will find the slider for permanent logging. This can be used to activate/deactivate permanent logging with each ignition change.

5.4 License

Under the *License* submenu, information about your data display can be found. Here you will find the serial number of your device and the currently installed software version.



Figure 10: License

Furthermore, you can enter the license codes to activate paid additional functions here. At the bottom of the screen, you will find feedback on the activated additional functions such as the Haldex license. If this is **red** no license is active, if this **green** is the corresponding function is active.

5.5 Gears

In the Gears submenu, the gear ratios can be entered for gears one to eight. Based on the ratios stored here, the display shows you the gears in the internal *sensor Gearcalc*.

The gear ratio is defined as follows:

$$gear\ ratio = \frac{RPM\ [\frac{1}{min}]}{speed\ [\frac{km}{h}]}$$

To enter the gear ratios, simply click on the corresponding gear and then enter your gear ratio there via the opening keyboard.



Figure 11: Gear device

To save you time, nerves and a calculator when setting up your gear indicator, we have created a setup gadget in the *Gears* submenu. When the vehicle is stationary, you will see too slow in the

submenu at the top right. If your vehicle starts moving, the display changes and you get your current gear ratio displayed at the top right of the screen (X). Now you can drive in any gear and then press on your data display on the corresponding gear to take over the ratio for this, turning off the engine is not necessary. Unused gears must be manually set to 0 when stationary.

5.6 Splash Screen

The *splash screen* is the start image/animation of your data display. In this menu you can set whether and for how long the *splash screen* should be displayed when your data display is switched on. By tapping the number, you can switch between off and a time of zero to ten seconds.

5.7 Start Page

Under Start *Page* you can set on which page your display should be after starting. Here you have the choice between sides one to ten or *last used*. With this option, your display starts on the side that was active when the data display was switched off. Switching between the different options is analogous to switching the *splash screen* by clicking on it.

5.8 Shiftlight

In the *submenu Shiftlight* you can configure the behavior of your **external** shift flash. Here you can set the color and the activation speed threshold for each of the eight switching flash LEDs by tapping them.

Furthermore, you can set the speed threshold (*RPM flash*), at which all eight LEDs start flashing. Other menu items are the global brightness of the LEDs (*brightness*) and the direction of the gradient (*left2right* or *right2left*).

5.9 Dim Sensivity

Under this submenu you can adjust the amount of dimming of your display via the essential function *Dim Display*5.3

ATTENTION: At 100%, the display is almost unreadable.

5.10 Pages

In the submenu *Pages* you will find a tab for predefined *widgets packs*. If you have stored them on your SD card, you can select and activate them here.

Pages X

For each page on your data display, you'll also find two sliders here.



Figure 12: Pages

The left slider locks or unlocks ("editable") the *pages* for editing. By default, editing is locked.

The right slider enables ("enabled") or hidden *pages*. With this function, for example, your display can only have three *pages* (page 4-10 hidden) and jumps back to the first page after the third *page*.

The last item of this submenu is the *orientation* of your data display. The user interface can be aligned in all four spatial directions. Horizontal, *vertical, horizontal2* and *vertical2* are available as options. After a change, a restart of the display is necessary. This can be done by disconnecting the power supply or by rebooting (described in Chapter 5.3).

5.11 Custom Button

The *custom button*, if activated, can be found at the bottom right of the *quick access bar*. By clicking next to the *Custom Button* lettering in the *setup* you can switch through the possible options.

As of software version 4.008, the following options are available:

Option	Description
OFF	The custom button is not active and is not displayed
Sleep	Display turns black and only lights up again with the next touch
Reset Max	Resets the operating maximum values of the sensors
Can Switch	Quick access to one of the 8 can switches
Panic	Fixed display of 3 bar charts, touch is deactivated
Can Switch	Can Switch 1, 2 or 3 for fast access

Table 2: Custom Button

The pin for the panic button can be set via the Set Pin button. By default, the pin is set to 0000. If you have forgotten the pin, you must flash your display via CANcheckedUpdater with the reset-to-default_GEN2.hex from the Gen2 download area of our website to regain access.



Figure 13: Position of the Panic Button



Figure 14: View during active Panic Button

If you have activated the panic button and are on the view with the three fixed bar graphs, you have to hold the touch screen down in one place for at least three seconds to access the keypad to enter the pin.

5.12 Demo Mode

The slide switch for the *demo* mode activates the demonstration mode of your data display. In this mode, all *sensors* created in the *TRI/TRX file* will oscillate between their *minimum* and *maximum value*. For example, you can use this feature to show your friends how cool your new data display is.

However, this function is particularly interesting when setting up new *pages* to simulate later operation and to get an idea of how your freshly created page will look in later use. The demo mode can also be started directly from the program during setup with the 9.3(chapter 9.3).

5.13 Too Soon Junior

You've worked your way through the *setup* and come across *Too Soon Junior*? Does the sentence sound familiar to you somewhere? Congratulations, you've found the first Easter Egg. Activate the slider, close the setup and push your accelerator to the ground.

(The *sensor* TPS or throttle must be in position number 26 in the *TRI/TRX file* for this easter egg to work)

Rev 1.2

5.14 Night Mode

You can use this slider to change the entire menu navigation of your MFD28/32 Gen2 from the bright daytime version to the darkened nighttime version. This setting is not reset with the next display restart but remains active until you change it again.

5.15 Units

Depending on the TRI/TRX file, you can set the units to be used here. To do this, please **ensure that a metric TRI/TRX file (X-XXX-M) is loaded**, and the sensor type is assigned for each sensor. **If an imperial or mixed file is already being used as the basis, the display will not calculate plausible values** when changes are made in this menu! Please compare chapter 6 column position 26. If you have a TRI/TRX file with only 25 column positions, you can add the sensor type manually in the DSS. Please refer to chapter 9.2.

6 The TRI/TRX File

The TRI or *TRI*. *TRX File* is the heart of your data display. All *sensors* and the associated information are stored in the *TRI file*. In principle, every *TRX* file is a *TRI file*, but some information is encrypted in it. Data displays for freely programmable engine ECUs are always delivered with *TRI* File and data displays for vehicle-specific protocols are usually delivered with *TRX File*.

In the following, the structure of a TR*I/TRX file* is explained. If you open the file with a text editor, you will find the following structure:

Each line represents a sensor and all metadata associated with the sensor. These 26 metadata are in columns, separated by semicolons. The decimal separator is a period, not a comma. The figure below shows a *TRI file* with two sensors (RPM and CLT) and the metadata associated with the *sensors*.

Figure 15: TRI File in the text editor

The column position of the 26 metadata is fixed in each row. For example, the Can *ID* of the respective *sensor* is always in the second column.

Table 3 shows the column positions, the designation, the purpose and peculiarities of the metadata. The values marked in <u>blue</u> are only visible in *enhanced mode in DSS* (more on this in chapter 9.2.2).

Table	3:	TRI/TRX	data
-------	----	---------	------

column position	Designation	Purpose and particularities			
1	Header	bus header for OBD/UDS (hexadecimal) 0 = no protocol			
		or specific Can Bus Identifier for protocol			
2	Can ID	Can Bus Identifier (hexadecimal)			
		when using OBD/UDS/TP2.0: Address for querying the device			
3	Format	0 -> Big endian; 1-> little endian; 2 -> VEMS (serial);			
		4 -> IEEE-754 float (Lenght=4)			
4	Start byte	First byte in Can Bus packet (0-7)			
5	Length	Length in bytes - 1, 2 or 4			
		for AINs: Attenuation strength 0-249 (0 = no attenuation)			
6	unsigned	if the value is negative, please do not tick the box			
7	shift Bit	moves the bit within the value to the right by position X			
8	CAN Mask	Masks the value before shift (0 -> no mask applied)			
9	Decimal places	Number of decimal places			
10	Sensor Name	Sensor name (maximum 15 characters, no special characters)			
11	initCalc	Can Bus value gets multiplied by this number			
		Result= ((Can Bus value & MASK)>>SHIFT) *INITCALC+INITOFFSET			
12	initOffset	after multiplication this value is added			
13	Multiplex /	OFF, MAP (linear analog sensors); NTC (3 constants and pull-up			
	Mappertype	resistor (Steinhart-Hart))			
14	start bit /	Multiplex start bit /			
	MapperInfo1	Varies by mapper type			
15	bit length /	Multiplex bit length /			
	MapperInfo2	Varies by mapper type			
16	Multiplexer /	Multiplexer /			
	MapperInfo3	Varies by mapper type			
17	Multiplier /	Global multiplication factor for the sensor (default value 1) /			
	MapperInfo4	Varies depending on mapper type			
18	AIN active	Internal analog sensor only; enables input pin polling			
19	Min	Lower warning value			
20	Max	Upper warning value			
21	RefSensor	reference sensor: only if the RefValue for this <i>sensor</i> is exceeded,			
		warning is active			
22	RefValue	Reference value for enabling the alert			
23	-	Not in use			
24	Рор	Popup active when exceeding or falling below the warning value			
25	-	Not in use			
26*	Sensor type*	Used for units calculation: 0=none; 1=pressure; 2=temperature; 3=speed; 4=combustion ratio			

*not included in all files - add via DSS if required or request by e-mail

6.1 Name encoding of TRI/TRX files

Our TRI/TRX files always have the following name:

$$X - ABC - X.TRI$$
 or $X - ABC - X.TRX$

The first letter identifies the *protocol* used. More information on the *protocols* can be found in Chapter 6.2

The letters two to four identify the engine code letter or ECU. The engine code DAZA becomes X-DAZ-X or a Syvecs ECU becomes X-SYV-X here. For freely programmable ECUs, however, the names can also be longer than three digits (e.g. MaxxECU -> X-MAXX-X). The maximum number of digits including ending is 8 characters.

The fifth or fifth last letter in the name of the *TRI/TRX file* indicates the units or languages used to name the *sensors*:

- -G stands for the language German and units metric
- -M stands for the English language and the units metric
- -I stands for the language English and the units imperial
- -H stands for hybrid here is the language English and the units partly imperial, partly metric, more detailed information can be found in the enclosed Quickstartguide
- -U stands for UK, here is also a mix of imperial and metric data

6.2 Protocols

CANchecked data displays support a variety of CAN protocols. For the different protocols, there are different firmware for your data display:

•	standalone engine control units (ECUs) use the standard firmware	(S-ABC-X. TRI)
•	Direct access to the vehicle Can Bus	(S-ABC-X. TRX)
•	Data retrieval with OBD2 protocol uses the OBD2 firmware	(O-ABC-X.TRX)
•	the TP2 protocol is used with the TP2 firmware	(T-ABC-X.TRX)
•	Vehicles that allow UDS protocol use the UDS firmware	(U-ABC-X. TRX)
•	BMW E/F series for vehicles of the E and F series	(B-ABC-X. TRX)

Depending on the installed firmware, you will only see TRI/TRX files for the corresponding firmware in the *TRI/TRX* selection list of the display. All files for other firmware will be hidden. For example, if OBD firmware is installed, you will not see TRI/*TRX* files for standalone ECUs, but only files with "O-". More information on changing and updating the firmware can be found in Chapter 8.

6.3 TRI/TRX file problem

If your data display starts and no *TRI/TRX file* is selected or present on the display, you will receive an error message in a large yellow box.



Figure 16: TRI/TRX error message

To select a TRI/TRX file , navigate to the list of files available on the SD card via Setup -> Can Bus -> TRI/TRX File.



Figure 17: TRI/TRX Selection Submenu

Now you can select your engine code/ECU from the list and by clicking on the corresponding file the name of the file will be transferred to the *load file* button. Now you can press *Load* file to load and activate the *TRI/TRX file*.

If you can't find your engine code or ECU in the list, there can be two different reasons:

- There is the wrong firmware on your data display, so that the files of the *desired protocol* are hidden (see chapter 6.2)
- The desired *TRI/TRX files* are not on your SD card and must be added later.

You have two options for adding the files to your data display:

- 1. Remove the SD card from the display, insert it into a computer and then copy the *TRI/TRX files* to the "can" folder on your SD card.
- 2. Establish a USB connection to the display and load the files onto the display via *the DSS*. More information can be found in chapter 9.6

No matter which of the two ways you choose, you have to select the *TRI/TRX file* on the display as described above.

7 Adjust on the display

While with the Gen1 CANchecked data displays almost everything could be configured on the display, the possibilities to set up the sides on the display itself have been significantly reduced with the Gen2.

To improve the setup of your data display, we've put even more work into customizing your display using *DSS*.

Nevertheless, you can adjust your data display a little even without a PC. Not all Widgets described in chapter 9.3.2.3 can be configured on the display. Which widgets you can customize on the display and what you can change with them can be seen in the table below.

Before that, the page must be unlocked in *the setup* under *pages*.

Widget	Possible changes		
vertical bar	MinValue, MaxValue, zugeordneter Sensor		
round meter	MinValue, MaxValue, zugeordneter Sensor		
YT diagram	Zugeordneter Sensor		
sensor vrange	Zugeordneter Sensor		
G-meter	MaxValue		
horizontal bar	MinValue, MaxValue, zugeordneter Sensor		
needle	MinValue, MaxValue, zugeordneter Sensor		
theverlay	MaxValue, zugeordneter Sensor		
performance meter	Zugeordneter Sensor		

Table 4: On the display customizable Widgets

It is not possible to change the size or position of widgets on the display. This requires a connection to the *DSS*.

When changing the widgets on the display, it is very important to check how many widgets are on top of each other at this point before changing them. To do this, you can dig a layer deeper into the user interface with each click on the display. For example, the *predefined page TrackView* has five layers on top of each other, while the *DailyDash* has three layers.

In the event of a change, attention must be paid to the selection of the correct *widget*. As soon as the first *widget* is selected, it is marked by a red box. The lower part of the display now shows which *widget* it is. If you click OK you close the edit mode, you tap again on the corresponding place and your display switches through to the next layer. You can click until the selection fields for the possible options are gone again, now you are through all layers and can start all over again.

In the image below, the three layers of the *DailyDash* are visible.



Figure 18: The three layers (round meter, overlay and sensor value) on the DailyDash

With the *DailyDash* are not only three layers above the large boost pressure display, but also above the three small round displays arranged on the side. If a *sensor* is changed here, it must be adapted for all three *widgets*.

8 Flashing the firmware

To change or update the firmware installed on your display, you must use our CANchecked Updater. You can find it on our website under Downloads MFD28/32/32S

(https://www.canchecked.de/downloads/mfd28-mfd32-mfd32s-mfa28-updatesoftwareaktualisierung/). The updater is available for Windows and Mac.

ATTENTION: Windows **7** still requires a **driver**. This can also be found in the MFD28/32/32S download area.

After unpacking and starting the updater, you should find the user interface shown in the image below.

CANchecked Updater	_		×
Actions Help			
			\sim
Lpload Reset		C	HECKED
			ī

Figure 19: CANchecked Updater

After inserting your display, your PC/Mac should recognize the display and automatically identify it as an available device in the updater and display it as a serial USB device.

CANchecked Updater	_		×
Actions Help			
USB Serial 11091540			\sim
Lpload Reset		C	CAN HECKED
	_		

Figure 20: CANchecked Updater with connected display

Before you can start updating your display, you need to download the appropriate firmware from our website. In the download area you will always find the latest version for your display. Here you can find the right firmware 6.26.2).

For your Gen2 data display, the firmware has the following format: <u>CANchecked_v4.XXX [protocol].hex</u>

By clicking on the corresponding firmware, you can download it to your PC/Mac.

If you have downloaded the firmware to your PC/Mac, you can now continue in the CANchecked Updater. By clicking on the upload button in the CANchecked Updater, the folder structures can now be searched. Now navigate to the directory where you saved your firmware, select it with a mouse click and press Open. In the CANchecked Updater, a green loading bar now runs through the user interface and the display restarts (exception when installing an init file*, here the display only starts again after installing a regular software).

CANchecked Updater	_	×
Actions Help		
USB Serial 11091540		\sim
Lpload Reset		

*Must only be installed when the data display is no longer accessible and must be requested by technical support (<u>info@canchecked.de</u>) if necessary, please send a description of the problem situation and development

Figure 21: CANchecked Updater with loading bar during the update

As the charging bar passes through, your PC/Mac will hear the sound that comes out when the USB connection is disconnected and restored. Then your display reboots regularly and is now ready for use again.

9 Customizing the display on the PC with the DSS

To make your data display unique, you can't avoid our *DSS*. You can download the *DSS* for free from our website at <u>www.canchecked.de/dss/</u>. This is available for both PC and Mac. On our website you will find a quick guide to download and install. Furthermore, you can find the **driver** required for **Windows 7** here. As soon as you have installed the *DSS*, you can execute it, should be able to see the following start screen and click on the CANchecked logo to get to the selection field of the device to be connected.



Figure 22: DSS startup

Here you click on the selection field for Gen2 devices (right) and now get to the tab overview. The following tabs are available:

- Connection
- TRI Editor
- Pages
- Log Viewer
- Other settings
- Upload
- Can log

Basically to **avoid problems**, we strongly recommend always establishing a connection to the display and **not** working offline.

9.1 Connection

To connect to your data display, you have to click on the *Connection* tab in the tab overview.



Figure 23: DSS tab overview

By now at the latest, you should have connected your data display to your PC/Mac via USB. If this is the case, you can select the data display as an available COM port from the list on the left side of the screen and establish the connection by clicking on it.

Attention: After **plugging** in the USB cable, please **wait until** the **start animation** has **run through** on the display before the connection is established in the *DSS* to avoid a disconnection. The display is supplied with power via the USB cable. You can leave the ignition switched off.

If you have several COM ports to choose from, please try which port your display uses to communicate with the PC/Mac. If you have found the right port you will get connected OK as a message and the frame around the connection tab will turn green and the import of the pages will start. During the import of the pages your display automatically switches through all pages. The connection and the loading of the pages can take up to one minute.

If you have previously activated the enhanced mode in the upper corner, a popup opens to deselect certain import functions. More about this mode in chapter 9.2.2.



Figure 24: Importing the Display Configuration

If the slider is set at the first selection field, all pages of your data display are actively imported into the DSS.

Only if this slider is active, you can call up an overview of all pages in the Pages tab. More about this in chapter 9.3.

If the slider for the second selection field is active, the TRI Editor is emptied before the sensors are imported from the data display. Caution: Only deactivate this slider if you know what you are doing. If the slider is deactivated, it can happen that there are duplicates in the TRI Editor and in the worst case you make your TRI/TRX file unusable.

Since firmware 4.007c, you can save the complete display configuration in the *connection* tab. Currently, this function is only used internally and for root cause analysis. The installation of other display configurations is planned for the future.

9.2 TRI Editor

In the *TRI Editor*, all sensors of your data display can be found after the import. In addition to the *sensors* that come as can messages on your display, you can also create and parameterize the four analog inputs here.

Attention: When the display is fully set, the position of the sensors in the *TRI/TRX file* should not be changed by deleting or moving, as this refers to the position of the *sensors* in the *sensor init* and on the *pages*.

9.2.1 Handling

Below the tab overview you will find the buttons of the *TRI Editor*. The button is divided into four sections.

Connection	TRI editor	Pages	Log viewer	Other settings	L Upload	Can log	$\langle \rangle$	\prec
DBC file OBD2 PIDs	TRI file *.lbl File	save to file ir	mport from display export to display	add sen	isor custom	additional info - select -		enhanced mode OFF

Figure 25: Buttons in the TRI editor

In the first area, you can import *sensors* from different data formats into the *editor*. Possible formats are:

- DBC Files
- TRI Files
- OBD2 PIDs
- *.lbl Files

In the second area you will find the function buttons for saving the TRI file currently loaded in the TRI Editor, the command to delete the *sensors* from the TRI *Editor* as well as the buttons for importing and exporting the *TRI file* from or to your data display.

The third area can be used to add internal and custom sensors. The internal sensors include:

- AIN1
- AIN2
- AIN3
- AIN4
- AIN5 (only for MFD15 Gen2)
- AIN6 (only for MFD15 Gen2)
- displayVolt
- displayTemp
- PWMoutDuty
- GearCalc
- FreqIn1
- MathChannel1
- MathChannel2
- MathChannel3
- MathChannel4
- MathChannel5
- MathChannel6

- MathChannel7
- MathChannel8
- Usertable1
- Usertable2
- Usertable3
- Usertable4
- Usertable5
- Usertable6
- Usertable7
- Usertable8

The fourth area can be used to get a quick overview of the individual information about the *sensors*. Simply select the desired information and compare it directly.

To set the *min* and *max warning values* for each *sensor* in the *TRI* click on the corresponding *sensor* to open the popup for editing.

		Sensor: Speed	S S
Decimal places	1	?	
Name	Speed	- ?	
Multiplier		- ?	
Min	-1.00	?	
Max	250.00	?	
Рор		?	
Apply			

Figure 26: Popup to Edit the Sensor in Normal Mode

In addition to the *min* and *max* warning values, you can also assign/change the names of your *sensors (maximum 15 characters – no special characters)* and switch popups for the *warning values* on and off. After you have changed/renamed the sensor, you have to confirm the changes with the *Apply button*. Once you have adjusted all *sensors* according to your wishes, you can transfer the changes to the data display via the *export to display* button on the button.

9.2.2 Global enhanced mode

The *enhanced mode* can be found in the upper right corner of the button bar. If this is not active, the pages and sensors can only be configured in a rudimentary way, and the Can Log tab is not available.

As long as the enhanced mode is deactivated, you cannot add new widgets to the pages and configure them only in the sensor mapping. The following subchapters describe the possibilities when enhanced mode is activated.

If you switch on the *enhanced mode*, you get even more possibilities to configure your sensors and the associated Can Bus details and reference sensors.

With the reference sensor, you can set the min or max warning even better. For example, if you set a min warning of 1.1 bar for the oil pressure, you will constantly get a pop-up even when idling. If you now specify the sensor speed as *RefSensor* with a *RefValue* of 3000, the min oil pressure warning will only be activated if the oil pressure is less than 1.5 bar, but only as long as the *sensor* speed has a value above 3000.



Figure 27: Popup for editing the sensor in enhanced mode

In addition, you now also have *the remove and* copy buttons to choose from with which you can delete, and copy can address and sensors. This function is especially handy when creating your own *TRI files*.

Please note that the pages point to the *sensor's* location, so if you delete *sensors*, you will most likely need to readjust your pages.

TRX files are only partially editable in *enhanced mode*. Encrypted values are marked with "****" and should not be edited.

9.3 Pages

In this tab you can adjust the individual *pages* of your data display. If you have ticked both boxes when establishing the connection, you will get an overview of all pages created on your data display by clicking on the *Pages* tab and can also switch from here to the individual view of the pages by clicking on them. In addition to hiding individual pages in the display setup on the data display itself, you can also hide or make visible the pages in the overview page by ticking the box.



Figure 28: Pages overview page with hidden pages

If the check mark for loading all pages was not set when connecting, you will land directly on the single view and must manually load the currently active page into the *DSS* by clicking on *import from display*.



Figure 29: Pages single view with button

Attention: If your data display is connected to the *DSS*, it is no longer possible to change the *pages* on the display by swiping gestures. When the connection is active, the pages can only be switched through by pressing the arrows in the single view. You can see which page is currently active by the small number below the *import to display* button.

Further functions in the single view are:

- *export to display*: Writes the currently loaded/created page in the DSS to your data display
- *load from file*: Imports a preconfigured page from another source
- *save to file*: Saves the currently loaded page to a location of your choice
- *helper lines*: Projects auxiliary lines into the *DSS* for easier **arrangement of** widgets via drag and drop
- clear view: Deletes the currently loaded page in the DSS and lets you start on a blank screen
- *load predefined page:* Here you can load preconfigured **pages** into the *DSS* with one mouse click and then write them to your data display via *export to display*

Below the load predefined page button, you will find a *Animate* slider. With this slider you can activate the *demo mode* (see chapter 5.12) from the *DSS* and then see how the *widgets* behave during operation. When positioning your widgets, please pay attention to the position on the data display as the positions in the DSS preview are not 100% accurate.

After changing your pages, please always remember the export to display feature before your hardearned changes end up in nirvana.
9.3.1 predefined pages

We are constantly expanding our *predefined pages*. By clicking on the *load predefined page* button, you get the names and a preview of the corresponding pages displayed and can load them into the DSS by double-clicking. So far, you can choose from these views:

- AirflowLogging
- BasicLogging4cyl
- BasicLogging5cyl
- BasicLogging6cyl
- BasicLogging8cyl
- DailyDash
- DPFinfos
- DriverDynamics
- FuelLogging
- Keypad
- MaxxECU
- Overview
- PerformanceMeter
- RPMBar
- TrackView
- TuneDisplay

9.3.2 Widgets

To the right of the preview of the page, you'll find the list of *active widgets* on the page. The smaller the number of the *widget*, the further it is in the background. For example, *widget* 5 is always above *widget* 4. Typically, *widgets* 0 and 1 are smaller logos or backgrounds.

You can arrange the individual *widgets* in the list by **dragging** and move it to the desired layer.

If you select a widget in the preview, the corresponding widget is marked with a red + in the list of active *widgets* and the submenu for the *widget* opens. If you click on the red symbol again, the submenu will collapse again. The individual submenus and widgets explained in the following chapter.

If you uncheck a widget in blue, the widget will be made invisible in your preview in the *DSS*. You can use this function to create *widgets* in different layers in the same place without accidentally clicking on it.

In addition to the number of the widget, you can also see at a glance what kind of *widget* it is. In addition, you can see in square brackets which *sensor* or image is assigned to this *widget*.

If something is unclear during setup, you can always press the red circle with the question mark to get more information about the corresponding widget or setup.



Figure 30: List of Active Widgets

Use the *Add* widget button to add a new widget to your site and then select which widget it should be from the drop-down menu. Once you've added a new *widget*, you can drag and drop it onto your page. The different ways of configuring the *widgets* (submenus) are discussed individually for each *widget* below.

9.3.2.1 General

In the display options of your *sensors*, you can choose from 20 *widgets* to have all important information at a glance. In the following, each and the configuration options of the *widgets* within the *DSS* are explained.

In general, almost all widgets can be changed in their position, color and size. The position and size are given in X and Y coordinates. The coordinate system is visible in the preview next to and below the preview window. The coordinate origin is in the upper left corner and corner. The bottom right corner has the coordinates 320/240. You can either drag and drop individual widgets with the mouse or select them with the mouse and then arrange them with the arrow keys.

Depending on the type, a *sensor* must be assigned to the *widget*. When creating a new *widget*, the first *sensor* of the currently loaded *TRI/TRX file* is always selected. To delete a widget, it can be deleted after selection by pressing the *Delete widget* button. A maximum of 64 *widgets* can be created per page.

For easier arrangement of the widgets, the Grid lock function can be used. This is located at the bottom of the preview window. If the function is activated, the widgets automatically snap into place for easier arrangement. A good starting value for this feature is 20 pixels.



Figure 31:Auto Grid lock

9.3.2.2 Color selection

For most widgets, you can configure the colors. Color gradients, font colors and background colors are freely configurable. The color wheel shown in the figure below is used to adjust the colors. In the outer circle you specify the base color, in the inner square the brightness or darkness. The color is then always written as hexadecimal code in the corresponding field of the widget and can be marked and copied here to be applied to other widgets.

Special feature: If the colour of the background (bg colour) is identical to the colour of the font (font colour), the background becomes transparent.



Figure 32: How the Color Picker Works

9.3.2.3 vertical bar

The vertical bar is a vertical bar chart and can be used wonderfully to display and compare temperatures or pressures. This is freely configurable in both size and color. A gradient is also possible.



Figure 33: Display view of the vertical bar widget for comparing three pressures

When it comes to the course of the vertical bar, you can choose from three options:

- Ascending from bottom to top (*bottom2top*)
- Falling from top to bottom (*top2bottom*)
- Horizontal line as pointer (bar)

Furthermore, a colour for the lower values and a colour for the upper values can be defined. For optimal design of the display area, the lower or upper limit of the *vertical bar* can be set at *min* value and *max value*. If these limits are set to 0, the values of the corresponding *sensor* from the *TRI/TRX file* are used.



Figure 34: Configuration vertical bar

In the previous example, the sensor was assigned *to OilT*. Thus, the *vertical bar* is blue first and then turns red with increasing oil temperature.

If the check mark is set at *show* name, the name of the assigned *sensor* is displayed in the lower area of the *vertical bar*.

Since 4.007c, the vertical bar can also be set with an angle. Rev 1.2

9.3.2.4 round meter

The round meter is a classical display, which is already known from the Gen1 CANchecked data displays. Different sizes and color gradients are possible here. In the figure below, one large and four small round meters with different color gradients are visible. The central value does not belong to the round meter widget but is a separate *sensor value* widget.



Figure 35: Display view different round meters

As with *vertical bar*, the color gradient of the *round meter* can also be adjusted. The name can be changed in size and position (*offset*). As with the *vertical bar*, the min value and *max value* functions can be used to set the values for the start and end of the *round meter*.

The position of the start and the end can be adjusted in angles, where 12 o'clock stands for 0 degrees. -120 degrees is eight o'clock and 120 degrees is four o'clock. The *ghost time* function can be used to generate a split-seconds pointer. With this, the pointer stops for a few milliseconds after the peak and facilitates readability during operation.

	Widget 0 - round me	ter
	round meter	· ?
	x coord	287
	y coord	66
ΙΛΤ	radius	30
	thickness	10
	sensor	IAT 🔻
	font size	2 🔻
	colour1	FEE0
	colour2	FB00
	min value	0
	max value	60
	start angle	-90
	end angle	90
	ghost time	0
	name offset	-7

Figure 36: Configuration round meter

In the example shown above, the *sensor* IntakeT was assigned to the *round meter*. The scale here only extends from nine to three o'clock with minimum and maximum values of 0 and 60 degrees.

9.3.2.5 YT diagram

The *YT diagram* is also known from the Gen1 data displays. With this widget you can display the history of a sensor value over time. Ideal for a direct overview of the peaks of your sensor readings after a pull.



Figure 37: Display view of a YT diagramwith four graphs

The chart can be varied both in size and position. Only one *sensor* can be assigned to each diagram. If several *sensors* are to be displayed simultaneously in one window, several *YT diagram widgets* must be superimposed.

😑 Widget 0 - YT diag	jram
YT diagram	· ?
x coord	292
y coord	34
x size	20
y size	50
sensor	TPS 🔻
delay in ms	0
colour1	07E0
colour2	09E0
min value	0
max value	100
ticks length	10

Figure 38: Configuration YT diagram

A delay can be implemented (delay in milliseconds). Furthermore, the color of the graph and the underlying surface can be configured. If the **two colors are identical**, the underlying surface becomes **transparent**. *Min* value and *max value* specify the lower and upper bounds of the y-axis, respectively. With *ticks length* you can set a small mark every X pixel to better divide the X-axis.

9.3.2.6 Enumeration

With the *enumeration widget* you have the possibility to display numbers in text. So, you can display error codes in plain text. For example, a "1" received via the Can Bus could be shown on the display as "No errors deposited". A "2" received via the bus, on the other hand, could mean "engine malfunction – check engine". A gear display can also be realized via this. For the corresponding representation, a text must be assigned to each possible number.

Like all other widgets, you can adjust the position and size of the widget via x coord, y *coord*, x size and *y size*. You can adjust the size of the displayed plain text via the *font* function. Here you can set font sizes from 0-9, where 0 is the smallest and 9 is the largest. As with other widgets before, you can *set* the font color via colour. In the following illustration, the *enumeration widget* is used to display the states of the EGT alarm.

😑 Widget 0 - enumerat	ion
enumeration	v ?
x coord y coord x size y size sensor	266 36 50 45 EGTALARM
colour colour centered alternating	FFFF
alternating time enum (check '?')	1000 on#off

Figure 39: Configuration enumeration

The status is displayed right aligned by default, if the check mark is set at *centered*, the text is displayed centered. The alternating function switches between the individual plain texts if several are active at the same time. *Alternating* time determines the time to switch in milliseconds. In the *enum* field, the corresponding plain texts can be entered with a hash as a separator. If no value is to be displayed as an enumeration, a space must be set (State1##State3).

9.3.2.7 Icon

The *icon widget* can not only be used to beautify the pages and make them look more appealing. Rather, it can also be used to concisely display the states of sensors. For example, a red icon can signal that a certain pressure or temperature has been exceeded or undercut. There are no limits to your imagination, and you can choose from a variety of predefined icons. The icons can be changed in size and color. In the image below you will find a small selection of the possible icons.



Figure 40:Display view with selection of icons in different colors

Similar to the *enumeration* and *status rectangle widget*, states of *sensors* can be mapped here using logical operators (==; >, >=; <; <=).

To beautify the pages, the same color must be assigned to both states, so that the *icon* is displayed permanently and independently of *sensor* and status. If a 0001 is entered at colour, this state becomes transparent.

Like the other *widgets,* the *icon* can be changed in size and position. The size of the *icon* itself is not set via *x* and *y size* but via *font*. *X* and *y* size only change the size of the *widget's* frame so that it can be clicked better or worse in the preview.

In the following example, the *icon widget* is used to monitor the state of the oil pressure. If the oil pressure is less than the value entered in value, the oil can will flash red, if the value is greater, the oil can will flash green.



Figure 41: Configuration icon

9.3.2.8 sensor value

With the *sensor value widget,* you can display a sensor value as a simple number. The number of decimal places is specified by the *TRI/TRX file*0



Figure 42: Display view for comparing pressures using the triple sensor value widget

If you like a frame around the widget better, you can also activate it and adjust its color. A representation of the optics can be found below.

Exceeding the max value (red background) or falling below the min value (blue background) can also be activated individually for the widget.



Figure 43: Display view of the sensor value widget with frame

You can adjust the numerical value in font, position, *font* colour, bg colour and *frame colour*. As with the YT diagram, the background becomes transparent if the three colors have the same color.

In addition to the previously mentioned options, you can now also edit the display type of the sensor value. Here you can choose between normal numbers (Font 1) and 7-segment numbers (Font 2).





The functions *low* warn colour and *high warn colour* refer to the min and max values from the TRI/TRX file if the min or max value from the TRI/*TRX file* is below or exceeded, the entire box (x/y *size*) of the *sensor value* colors in the color you selected.

	😑 Widget 0 - sensor va	lue
	sensor value	· ?
	x coord	248
RPM 0	y coord	24
	x size	70
	y size	45
	sensor	RPM •
	font size	4 🔻
	border radius	5
	font colour	FFFF
	bg colour	FFFF
1	frame colour	FFFF
	low warn colour	008F
	high warn colour	F800
	show name	
1	show max	
	min warn	
	max warn	
	centered	
	maximum	
	minimum	
	left aligned	

Figure 46: Configuration sensor value

By setting/removing the checkmarks, you can personalize your *widget* even further.

- show name ->
 - shows the name of the associated sensor
 - show max -> displays the maximum value of the current session as a small numerical value below the measured value one

•

- *m in warn* -> activates the color set at *low warn colour* when falling below the *min value* in the *TRI/TRX file*
- max warn -> activates the color set at high warn colour when the max value is exceeded in the TRI/TRX file
- *centered* -> centers the measured value within the frames (*x/y size*)
- *maximum* -> hides the current measured value and displays the maximum value of the current session
- minimum > hides the current measurement value and displays the minimum value of the current session
- *left alligned* -> moves the measured value within the frame lines to the left (x/y size)

9.3.2.9 Gear

With the *gear widget* you can display the currently engaged gear as a large number. The *gear widget*5.5*TrackView*.



Figure 47: Display view of the gear indicator in the rev counter of the TrackView

In automatic vehicles, the display of the gear (P; R; N; D; S).

Important for the error-free function of this *widget* is the correct assignment of the *sensors* in the *sensor init*. 5.3If gear *mode* is not assigned in the *sensor init*, only the gear is displayed. As shown in the image below, you can customize this *widget* in size, position (x/y coord), and font color. As with the other *widgets* before, x/y size only affects the size of the surrounding box and not the display itself.



Figure 48: Configuration gear

9.3.2.10 G-meter

The *G*-meter is a widget known from motorsport. The sphere shows you your longitudinal and lateral accelerations (unit: G). In addition, the maximum lateral and longitudinal accelerations achieved can also be displayed. Ideal for the next trackday to find the ideal line, just to improve your lap times or verify your aeromods.



Figure 49: G-meter as predefined page

If your *TRI/TRX file* has the *sensors* for lateral and longitudinal acceleration, you can use the *Gmeter*. With this *widget* you can display the acceleration/deceleration in the four spatial dimensions. The widget can be changed in size and position (x/y size). In addition, the size (*circle size*) and color (*colour*) of the point as well as the maximum value (max value) of the acceleration can be adjusted.



Figure 50: Configuration G-meter

9.3.2.11 can switch

The *can switch* widget is also already known from Gen1. With this widget you can save yourself a Can Keypad and use your data display as a keypad instead. Possible functions would be switching on and off additional devices such as pumps or fans or other hidden functions that you have integrated into your vehicle. The size as well as the colors of the switches can be freely configured. The figure below shows a switch. In this case, yellow is inactive and green is active.



Figure 51: Keypad with two switches (yellow inactive, green active) and one multiswitch

If desired, a pop-up inform-window can be activated in the DSS when switching the switches. This then appears briefly when changing the state of a switch. Switches can be designed as both rasters and buttons.

The settings for the *widget can switch* are as with the other *widgets* also position (x/y *coord*) and size (x/y *size*). Use the *function can switch* # to enter the number of your switch.

😑 Widget 0 - can switch	
can switch	, ,
x coord	238
y coord	23
x size	80
y size	50
can switch #	1 •
inactive colour1	07E0
inactive colour2	07E0
active colour1	F800
active colour2	F800
frame colour	07E0

Figure 52: Configuration can switch

In addition, you can configure the colors of the two states (*inactive/active*) via the color wheel. For each status you can configure two colors, including a gradient and the color of the frame color.

9.3.2.12 multi switch

A multi switch is a switch that can assume two or more states. This can be used, for example, to switch different boost levels or to configure the control of the ABS. This function can be used to emulate a rotary potentiometer, for example, with your data display.



Figure 53: Keypad with two switches and one multi switch in different states

Like all other widgets, the Multiswitch is configurable in size and number of states with our DSS.

The *multi switch* can have up to eight different statuses. Like the can switch, you can also change the *multi switch* in position (x/y coord) and size (x/y size).

	😑 Widget 0 - multi switch	
VV	multi switch	v ?
	x coord	238
	y coord	23
	x size	80
	y size	50
	switch #	multi switch 1 🔻
	font size	1 •
	state count (2-8)	8 •
	default val	1
	state 1 val	10
	state 2 val	20
	state 3 val	30
	state 4 val	40
	state 5 val	50
	state 6 val	60
	state 7 val	70
	state 8 val	80

Figure 54: Configuration multi switch

You can create the number one to four and, to control the Haldex, a fifth multiswitch. *Font* size configures the font size, *state count* defines how many states the *multi switch* can accept. *Default* val the state when starting the displays and state *x val* the values of the corresponding states.

The last (fifth) multiswitch is for the Haldex widget. To do this, you first need a Haldex license. Contact your dealer to purchase a Haldex license for Gen1 and Gen2.

The sixth multiswitch is for a low-side output. You also need a licence for this. Contact your dealer to purchase a licence for Gen1 and Gen2 units.

9.3.2.13 horizontal bar

The *horizontal* bar is analogous to the *vertical bar*. The horizontal bar chart can also be used to display and compare temperatures or pressures. This is freely configurable in both size and color. A gradient is also possible. In the figure below, the widget is used to display the opening angle of the throttle.



Figure 55: horizontal bar

With *the horizontal bar*, you can choose from three options:

- From left to right
- From right to left
- Vertical line as pointer

Furthermore, a color for the lower values and a color for the upper values can be defined. For optimal design of the display area, the lower or upper limit of the *horizontal bar* can be set at *min* value and *max value*. If these limits are set to 0, the values of the corresponding *sensor* from the *TRI/TRX file* are used.

😑 Widget 0 - horizonta	al bar	[TPS] 🗹 💳
horizontal bar	· ?	
x coord	198	
y coord	25	
x size	120	
y size	30	
sensor	TPS 🔻	
show name	no 🔻	
colour1	0FE0	
colour2	F800	
min value	0	
max value	0	
direction	left2right v	

Figure 56: Configuration horizontal bar

In the previous example, the *sensor* was *mapped to TPS*. Thus, the *horizontal bar* is first green and then turns red with increasing throttle position.

At *show* name, the name of the assigned *sensor* can be displayed in the lower area of the *horizontal bar*.

9.3.2.14 Needle

The *new* widget can be used to configure your own analog pointer displays (rev counter/boost pressure indicator). The *needle* widget can be scaled with the *DSS* exactly to the desired size. Both the size and the color of the pointer are adjustable. In the screenshot below, the *needle* widget can be seen on the predefined *TrackView*.



Figure 57: needle widget on the TrackView

Interesting with the *needle* widget is the drag pointer (shown on the picture as a transparent pointer) with which you can see the peak of the last milliseconds (function can be deactivated in the *DSS*).

Please put the matching speedometer disc as a *picture*. With *x/y coord* you can adjust the position of the widget as usual. With radius1 and *radius2* you can adjust the size of the needle. This is stretched between radius1 and *radius2*. The width determines the width of the needle. As with the other *widgets,* the *needle* must also be assigned a *sensor* and the color of the pointer is done as usual via the color wheel.

e Widget 0 - needle	
needle	• ?
x coord	268
y coord	81
radius1	50
radius2	20
sensor	Speed •
width	15
colour1	FFFF
min value	0
max value	0
start angle	-120
end angle	120
ghost time	0

Figure 58: Configuration needle

The menu items *min* value and *max value* are the lower and upper limits of the *widget*. If there are zeros here, the values for min. and max. of the *needle* are taken from the *TRI/TRX file*.

The menu items *start* angle and *end angle* refer to *min* value and *max value* and are, as already specified in the *round meter* in degrees, where 0 degrees is at 12 o'clock. For example, if you want a classic "6 o'clock speedometer" your *min value* is 0 and the *start angle* is -180.

As already known from the *round meter*, there is also a split-seconds pointer in the *needle widget*. This is configured via the menu item *ghost time*.

9.3.2.15 Overlay

With the *overlay* widget you can display flashing warnings regardless of the min and maximum warning values stored in the *TRI/TRX file*. You can freely configure the flashing frequency and color. The *overlay* widget can be found by default for various purposes (warning, shiftlight) on the following pages:

- DailyDash
- TrackView
- AirflowLogging

In the following figure, the *overlay* widget is used as a shiftlight. In this case, it is fixed to the *sensor* speed and starts flashing at a frequency of 60 Hz as soon as the warning threshold (6000 rpm) is exceeded.



Figure 59: overlay widget in both states on the TrackView

Depending on which *sensor* you assign to the *widget*, it can be used as a switching flash, as a warning or as a confirmation. Like the other *widgets* before, you can change it in size (x/y size) and position (x/y coord). In addition, you can choose between the round or the square shape (*rectangle, circle*). Also adjustable is the frequency (*time ms (x10*)) and the color (*colour*) with which the widget should flash. The point *value* describes the activation limit. If the current value of the *sensor* is greater than the value in *value*, the *widget* becomes active and flashes.

	😑 Widget 0 - overlay	
1	overlay	· ?
	x coord	267
	y coord	27
	x size	50
	y size	50
	sensor	IAT v
	time ms (x10)	0
	colour1	F800
	value	60
	overlay type	rectangle _

Figure 60: Configuration overlay

9.3.2.16 Pixel

The pixel widget is interesting for all users who use the *log* function. Those *sensors* created as *a pixel* widget are additionally queried and stored in the log file.

If you have now created an appealing page on which, for example, you monitor the boost pressure and the exhaust gas temperature and want to log along, but you would also like to see lambda and speed in the log without displaying these *sensors* as *widgets* (*round meter, sensor value*, etc.) on your new page, you can create the *pixel widget* twice. Once for the sensor lambda and once for the *sensor* speed. Now these two sensors are additionally queried and logged in addition to the *sensors/widgets* created on the page.



Figure 61: Configuration pixel

Of course, this *widget* can also be adjusted in size (x/y size) and position (x/y coord), but this does not play a major role because it is not visible on the display itself and only works in the background during logging or warnings. This makes it more important to assign the desired sensor in the log.

9.3.2.17 performance meter

You can use the *form meter* to test improvements to your vehicle **on closed test tracks**. The *form meter* is active and measures as soon as you are on this page. The following (best) times are stored:

- 0-100
- 0-200
- 100-200

ATTENTION: The speed is determined by the rolling circumference of the tires of your vehicle and is very accurate not **GPS-based**. A correction due to slope / gradient and tailwind or headwind does not take place.

A representation of the *form meter* can be found in the figure below.



Figure 62: Display view of the performance meter

Like the other *widgets*, the *performance meter* is also customizable in size (x/y size) and position (x/y *coord*). However, the size should not fall below a minimum size of 240x120 to ensure proper representation.

Analogous to the other *widgets*, the corresponding *sensor* (in this case Speed) must also be assigned here, and the units must be defined.



Figure 63: Configuration performance meter

9.3.2.18 status rectangle

The *status rectangle* widget can be used similar to the *icon widget*. It is also variable in position (x/y *coord*) and size (x/y *size*). Each of the two states can be assigned a color or a gradient using the color wheel. In the example below, the *widget* is used to map the state of cruise control. If a 10 (status *value*) is received on the bus, the status is activated, and the status *rectangle* changes its color from red to green.

	😑 Widget 0 - status rectangle	
	status rectangle	• ?
	x coord	248
·	y coord	23
	x size	70
	y size	40
	sensor	TableSet •
	colour1	F800
	colour2	F800
	frame colour	07E0
	status colour1	07E0
	status colour2	07E0
	status value	10

Figure 64: Configuration status rectangle

9.3.2.19 rectangle

The rectangle, like the *status rectangle*, is adjustable in size, position and color (gradient). It is not assignable to any *sensor*, so you can use it as a construction element for your pages. Due to the variable size and position, this widget allows you to draw fine lines to spatially separate your ads. You can also use it to create backgrounds for other ads. In the figure below, the *rectangle* was used to sketch the maximum deflection of the *vertical bar* above.



Figure 65: rectangle as background for the vertical bar

You can adjust this *widget* in position $(x/y \ coord)$ and size $(x/y \ size)$. Furthermore, you can use the color wheel to color the *rectangle*, provide it with a gradient and determine the color of the frame color.

Widget 0 - rectang	le
rectangle	• ?
x coord	267
y coord	26
x size	50
y size	40
colour1	F800
colour2	FFFF
frame colour	008F

Figure 66: Configuration rectangle

9.3.2.20 text field

With the *text field* widget, you can design your pages even better and create your own words or sensor names on your pages. The text fields can be changed in position and size and the size and color of the font is variable. **No special characters** may be used.

The text field can be configured as usual in position ($x/y \ coord$) and size ($x/y \ size$). A maximum of 32 characters is allowed per text field. Several text fields can be created per page.

In the example below, the background of the widget has been colored blue with the color wheel (*bg* colour) and the color of the font (*font colour*) has been changed. As with the other widgets, the **background** of *text field* becomes transparent if **bg** and **font** have **the same color**. Font *size* can be used to adjust the size of the font. By default, the font is left-aligned within the field, if the corresponding hooks are set, it can also be centered or right-aligned.



Figure 67: Configuration text field

9.3.2.21 picture

In addition to the text fields, you can also use the *picture* widget to make your *pages* more appealing or provide a custom background. In the figure below, the CANchecked logo and the carbon background are created as a *picture* widget.



Figure 68: Carbon background and CANchecked logo as picture widget

The position of the image can be defined as usual with x/y coord. The points x/y size do not determine the size of the image, but only the image section in the preview. The size of the image is determined by the size when uploaded. The screen measures 320x240 pixels. The recommended size for icons is 30x30 pixels, for smaller logos 100x40 pixels is recommended. If the desired image has been scaled appropriately and uploaded via the *upload* section and then be selected from the drop-down list in the *picture widget*.

CAN	Widget 0 - picture	
AHEAKED	picture	· ?
UNEORED	x coord	265
	y coord	32
	x size	50
	y size	50
	picture	
	CAN CC05	0.bmp
	blend colour	FFFF
	alpha blend (0-1	00)0
	ignore colour	0000

Figure 69: Configuration picture

The *blend* colour function can be used to specify the colour with which the image should be mixed. The strength of the mixture is configured via *alpha blend*, where the value 0 does not correspond to any mixture. With *ignore colour* you can determine which color becomes transparent within the image. This function can be used to crop logos.

9.3.2.22 RPM bar

The speed bar is already known from the Gen1. Of course, you can also assign other *sensors* to it. An illustration of the speed bar is visible below. Here, the *sensor* speed is assigned to the widget.



Figure 70: RPM bar as predefinded page

For example, an oil pressure indicator in digifiz style would also be conceivable. As with our other widgets, there are no limits to your creativity, and you can make the CANchecked data display your data display.

You can calibrate the *RPM bar* in position (x/y *coord*) and size (x/y *size*). In principle, this *widget* does nothing more than gradually fade in and out an image depending on a *sensor*. As with the *picture widget*, the colours of the image can be mixed or cropped using blend colour, *alpha blend* and *ignore colour*.

min value defines the lower threshold value for starting an overlay, and *max* value defines the value at which the image is fully displayed. Furthermore, the direction of the overlay can be defined:

- from left to right
- from right to left
- from bottom to top
- from top to bottom

Various predefined speed bars are possible. Due to the new design, however, specially designed speed bars can also be uploaded and used. For uploading and scaling, see Chapter 9.6



Figure 71: Configuration RPM bar

In contrast to the *RPM bar* of the Gen1 displays, other *sensors* can also be assigned to this *widget* with the Gen2. For example, it is possible to show or hide images/logos based on the accelerator pedal position.

Attention: you can only use **one** image for RPM Bar per page – i.e., several RPM Bar widgets with the same image.

9.4 Log Viewer

In the *Log Viewer*, the 4 To view a *log*, you have to navigate to the *Log Viewer* tab and import the *logs* stored on the data display into the *DSS* via *import from Display*. In this navigation bar you can also export *logs* to your PC or load them from your PC into the *Log Viewer*.





Figure 72: Overview Log Viewer

Once you have opened a *log*, the diagram will be displayed on the left half of your screen and the available sensors on the right half. Now you can select the *sensors* relevant to you from this list by clicking on them and display them in the diagram. With the mouse cursor you can stretch the relevant areas by clicking and pressing and zoom in and out via the zoom function in the upper right corner of the *log*.



Figure 73: opened log

To delete a *log*, please click on the red cross and confirm the deletion with ok.

9.5 Other settings

As with the *setup* on the data display itself, changes can also be made to the settings of the data display in the *DSS*. If changes are made here, they must always be transferred to the data display with the *write to display* button at the bottom left.

9.5.1 General settings

Under *General settings*, the dwell time of the start screen can be set by menu item *Start screen*. Here a duration of 0-5 seconds is adjustable.

•	General settings (Sta	art screen, Popup, Background Light, Rotation, Startscreen)	
	Start screen	1s •	
	Popup	active v	
	Popup Time	3s •	
	Background light	100% •	
	Dim sensitivity	OFF •	
	rotation	horizontal v	
) -	start page	last used ▼	

Figure 74: General settings

Furthermore, the popups and the dwell time of the popups can be defined under Popup and *Popup Time*. Further menu items are backlight (*Backgrounds light*), the sensitivity of the dimming (*Dim sensitivity*), the orientation of the display.

9.5.2 Can Bus

As in the menu on the data display itself, you can de-/activate the can scheduling in this submenu in the *DSS*, set the can speed, de-/activate the OBD2 29-bit extension and set a timeout for the next data query (timeout).

Can Bus (Can Bus Setting)	s)	Æ.	
Can term	inactive	•	
Can speed	500kbps	▼	
OBD2 extended (29bit)	inactive	•	
timeout	0		milliseconds to wait before next request

Figure 75: Can Bus

9.5.3 Shift light

This is analogous to the configuration of the shift light menu on the data display. You can adjust the speeds and colors of the shift light to the corresponding speeds. Under the menu item brightness you can set the *brightness* and under *direction* the direction of the shiftlight.

9.5.4 Gears

In the submenu *Gears* you can also specify the gear ratio for gear calculation.

9.5.5 Sensor init

Analogous to the setup on your data display, the *sensor init* settings can also be made directly via the *DSS*.

Sensor init (vita)	al sensor de	efinitions)
RPM	NA	▼ RPM sensor in your TRI/TRX file for gear calculation
Speed	NA	speed sensor in your TRI/TRX file for gear calculation
Page Switch	NA	send a page (0-9) via can bus to jump to this page
Dim Display	NA	dim display with a switch or value (0-255) 255=full brightness
Haldex Ext	NA	sensor to control haldex widget; set haldex widget to value 255
Gear	NA	gear sensor in your TRI/TRX file for gear widget
Gear Mode	NA	▼ gear mode sensor in your TRI/TRX file for gear widget

Figure 76: Sensor init

For most applications, it is sufficient to set *RPM* to the sensor speed , speed to the *sensor* speed and gear to the sensor gear. For automatic vehicles, *Gear Mode* can still be set to gear. The others are to be set to NA. The explanation of the functions can be found in the figure above.

9.5.6 IO pins (Dimming and page switch)

This menu item cannot be accessed directly via the setup of the data display. In this menu item, the pins for the *functions PageSwitch*, *Brightness* and *Frequency In* can be assigned and activated.

IO pins (addition	al pin usaថ	ges (inputs, outputs	s))
PageSwitch	OFF	•	
Brightness	OFF	T	
Frequency In	OFF	T	



PageSwitch can be used to switch from one side of the data display to the next by grounding one of the pins selectable in the drop-down menu. If you want to switch the page to 5V, it is necessary to install an external pull-up resistor (10K Ohm) to 5V.

The same applies to the *brightness pin*, so the display can be dimmed by an external switch. It is possible to dim against ground or against a 12V signal. Please refer to the description in the *DSS*. If you set the dimming to B1, for example, you can dim against a 5-12V source. One application here would be, for example, the voltage of the instrument lighting for dimming the display.

😑 IO pins (additional	pin usages - inputs, outputs)	
🔥 B1 and B6 o	nly usable from hardware v1.0a9 - REBO	OT after change 🚹
PageSwitch	B5 to ground (use 10K pullup to 5V)	✓ pull pin to ground to flip to next page
Brightness	B1 to 5-12V	→ dim display

In addition, the *background light* must also be set to determine how much the display should be dimmed. This can also be found in the *DSS* under *General settings*.

 General settings (Start screen, Popup, Background Light, Rotation, Startscreen, Logging) Start screen Popup Active Popup Time Background light 10% 			
Start screen	OFF ~		
Popup	active ~		
Popup Time			
Background light			
Dim sensitivity			

The *Frequency In* is used to feed 0-5 V square wave signals (e.g., wheel or charger speed) into your data display. For example, see our instructions for the FlexFuel Sensor (ethanol).

9.5.7 Can Transmit

In this menu item you can configure the start state (*Default status*), the behavior (*Momentary* = button, otherwise switch) as well as a pop-up window (*Inform*) for your can switches.

Can Switches		
Globally disabled		
Default status	0: 🖾 1: 🗖 2: 🗖 3: 🗖 4: 📕 5: 🖾 6: 🖾 7: 📕	Tick to activate switch on display startup
Momentary	0: 🗖 1: 🛡 2: 🛡 3: 🛡 4: 🛡 5: 🛡 6: 🛡 7: 🛡	Tick to activate momentary, otherwise latching
Inform	0: 🗳 1: 🗳 2: 🗖 3: 🗖 4: 🗖 5: 🗖 6: 🗖 7: 🗖	Tick to activate large inform window when changing a can switch

Figure 78: Can Switches

Furthermore, you can send up to four Custom Can Frames from your data display to the Can bus. The frames can be activated individually (*Activate*).

Can f	rame 1						
Active		enabled v					
Endia	n	little 🔻					
Value	s	2		H	ow many values to transmit in the	frame (1-7)	
Mess	age Id Ox	640		11	11bit Can Bus identifier in HEX		
Trans	mit rate	10 🔻		Da	ata rate in Hertz		
Data	Туре	variable	offset	multiply	divide		
1	uint8 fixed		420			(value + offset) * multiply / divide = send value	
2	uint16	▼ EthanolTemp	* 0	5000	1023	(value + offset) * multiply / divide = send value	

Figure 79: Can frame

To do this, the number of messages in the frame, the Base ID (*Message Id Ox*), the transmission rate (*Transmit rate*) as well as the Endiness (*Endian*) and the data type (*Data Type*) must be specified. The frame can then be filled with *sensors*, switches or fixed values. By clicking on *write to* display, the changes are reflected in the display.

Any settings you make here are at your own risk. So be very careful with the messages that are sent here.

9.5.8 User tables

The *User Table* can be used to combine two *sensors* into a common output. In the example below, a value between 0 and 100 is generated from the speed and accelerator pedal sensors, depending on the condition. This value can be used, for example, to control the actuation of a boost pressure control valve (N75).

Another conceivable application would be the control of a water-methanol injection (WMI) via the sensors IAT (intake air temperature) and boost (boost pressure).

Of course, only a 1D table can be created to store a characteristic curve. Regardless of whether it is a 1D or 2D table, the values on the axes must be arranged in ascending order. For this purpose, it may be necessary to transpose or invert some characteristic curves.

Via the *DSS*, the resolution can be set in 1 to 0.001 steps. The size of the *User Table* is set via the + and buttons next to the table. The sensors are assigned by clicking on the axis label (all *sensors* available in the *TRI/TRX file* can be selected).

Values can be entered by clicking on individual cells. In addition to the manual entry via the keyboard, the mathematical functions can also be added and subtracted as well as interpolated if several cells are selected.

User 1	Table 1					_/				_/			
Size	1	1x9(24	2bytes)									
Size 11x9 (242bytes) Resolution 1 from -32768 to 32767 8000 0 													
					•								
	8000	0	0	0	0	0	10	30	50	50	50	50	
•	7000	0	0	0	0	0	10	30	50	70	100	100	
	6000	0	0	0	0	0	10	30	50	70	100	100	
	5000	0	0	0	0	0	10	30	50	70	100	100	
도	4000	0	0	0	0	0	10	30	50	70	100	100	
ehza	3000	0	0	0	0	0	10	30	50	70	100	100	
	2000	0	0	0	0	0	10	30	50	70	100	100	
	1000	0	0	0	0	0	10	30	50	70	100	100	
	0	0	0	0	0	0	10	30	50	70	100	100	
		0	10	20	30	40	50	60	70	80	90	100	
					Ga	spedal		▼					

Figure 80: User Table

By clicking on the *write to* display button, the newly created *user table* is transferred to your data display. In order to use the *User Table* as output, it must be created as an *internal sensor* in the *TRI editor*.

After each change in the table or the axis scalings, the display must be restarted for the changes to take effect.

9.5.9 Math Channels

With the *Math Channels*, you can link *sensors* together through logical functions. You can add, subtract, multiply, and divide from the basic arithmetic operations with up to five variables (*sensors*) or fixed values Choose a total of up to eight *math channels*.

Rev 1.2

In the following example, the *power* in kW is calculated from the torque and speed sensors. The mathematical formula for the calculation is:

$$P[W] = 2 * \pi * M[Nm] * n[1/s]$$

1

With the torque in Nm and the speed in 1/min and the result in kW, the following formula results:

$\frac{2}{2}$	* 3,14 * sensor tore	que [N	[m] * sensor RPM	$\left[\frac{1}{min}\right]$
power $[kw] = -$	(50 * 10	000	
Math Channels				
Math Channel 1				
Function	(A*B*C)/(D*E)	•		
Resolution	0.1 • fr	om -32	276.8 to 3276.8	
Value A	fixed value	▼		6.3
Value B	sensor variable	▼	Drehmoment	▼
Value C	sensor variable	•	Drehzahl	•
Value D	fixed value	•		60
Value E	fixed value	•		1000.0

Figure 81: Math Channel

One decimal place is sufficient as a resolution here. Accordingly, a *resolution* of 0.1 is chosen. As in the *TRI Editor*, the **decimal separator is a period and not a comma**!

From the drop-down menu, select the most suitable calculation template, assign the variable and fixed values and click on the *write* to display button to transfer the newly created *Math Channel* to your data display. In order to use the *Math Channel* as output, it must be created as an *internal sensor* in the *TRI editor*.

9.5.10 Boost/PWM Control

In this menu the **paid** item *Boost/PWM Control* Addon can be configured. Although this function can also be configured in DSS without purchasing a license, it only becomes active when the license key is entered on the data display.

The (PWM) output can be controlled via the previously created *User Table* (*Assign Usertable*). The frequency (*Output Frequency*) and the PWM signal (*PMW output*) can be defined. Furthermore, the output can be inverted with the invert function. For boost control valves a frequency of 30 Hz is most common.

Boost/PWM Control			
Output setting			
Display restart require	ed on any changes bel	ow	
Globally enabled	3		this activates the output
Output Frequency	65535		0-65536Hz - read the documentation of the attached device
Invert	-		Inverts the PWM (100=0, 0=100)
PWM output	2		enables PWM output, otherwise it is just on/off
Assign Usertable	User table 1		Select user table for base PWM output (0-100%)
Correction functions	5		
add more percental d	uty cycle (positive valu	ies) (or decreases the duty cycle (negative values)
Correction function 1	User table 2	٠	changes the base output on a percental base: outputPWM = basePWM * (1+correction1/100)
Correction function 2	nothing assigned	•	changes the base output on a percental base: outputPWM = basePWM * (1+correction1/100) * (1+correction2/100)
Correction function 3	nothing assigned	•	Adds a 3rd correction factor
Correction function 4	nothing assigned		Adds a 4th correction factor

Figure 82: Boost/PWM Control

The output output can be corrected by further *user tables*. In the following example, the *boost output* is corrected (scaled) by a *table* with the gears. With this Boost by Gear, the boost pressure control valve is scaled down in the lower gears for more traction and scaled up even more in the upper gears.

User Table 2							
Size	6x1(30	bytes)					
Resolution	0.1	▼	from -3	8276.8 to	3276.8	3	
		Ð		•			
	0.5	0.7	0.9	1.1	1.3	1.5	
	1.0	2.0	3.0	4.0	5.0	6.0	
		Gang		Ţ	,		

Figure 83: User Table for boost correction

This function can also be used to map different power levels, provided that a potentiometer or switch is defined as axis scaling (*sensor*).

9.6 Upload

In the *upload* section of the *DSS* you have the possibility to transfer files to your data display. By clicking Choose *File*, you can search your computer for files and then upload them.

You can upload *TRI/TRX files* or upload logos and images that you want to add later to your pages via this button. The accepted data formats can be found below the button.

When uploading images and logos, it is very important to **scale** them to the appropriate size **before uploading**. For small icons we recommend a size of 30x30 pixels for logos a size of 100x40 pixels is recommended. The total screen size is 320x240 pixels. MS Paint can be used to scale the images and logos.

Rev 1.2


Figure 84: DSS Upload Section

If old images are overwritten, they must be deleted from the **flash memory** after successfully uploading the new image. To do this, please swipe down from top to bottom on the display after uploading, click on Setup -> *Sensor Init -> Erase flash*.5.3

In addition to uploading your own images and files, you can upload internal *DSS* images and *TRI/TRX files* via the lower area of the *upload* section. Please select this from the drop-down menu and start the upload to your data display via the upload button.

9.7 Can Log

The Can *Log* section of the *DSS* can be used to look for Can-IDs and frames or message packets and to sniff Can messages.

By clicking on *Start Log*, the received Can Bus data is displayed. The stop is done via the same button. *Clear* Log deletes the Can Log.

9.8 Work offline

The data display does not need to be permanently connected to the *DSS* to work with the *DSS*. For example, *TRI files* can be created offline, or page layouts can be configured.

However, there are the following points to consider:

- *TRI files can also be loaded* from the hard disk into the *TRI editor, TRX files* can only be loaded from the data display into the *DSS*
- In the TRI editor sensors must be loaded, otherwise only NA is displayed in the Pages section for all sensors and widgets
- The preview of the *widgets* in the *Pages* section is not 1:1 identical in terms of font size, and should therefore be done online on the display

For this reason, working without a connected data display is not recommended, but is possible in principle.

10 AIN Setup (analog inputs)

Your display has 4 analog inputs with 10bit resolution (0-1023).

Already successfully tested and installed sensors as well as their characteristic curves and connection diagrams can be found under <u>www.canchecked.de/downloads/</u>. The analog inputs can display a maximum voltage of 5V, but can also tolerate voltages of up to 14 volts.



Figure 85: Connecting the AINs

The *analog inputs* are also set up via the *DSS*. If your TRI/TRX file does not yet have a sensor for an *analog input*, you can add it to your *TRI/TRX file* as described in chapter 9.2 via the *add sensor-internal* button by selecting the corresponding AIN(s), scrolling down and clicking on *Apply* button. Now you have to activate the *enhanced mode* in the upper right corner (see chapter 9.2.2) and can then configure the sensor by clicking on the corresponding AIN. You can change the name, adjust the attenuation, choose the type of mapper and of course activate the *analog input*.



Figure 86: Adding AINs

The mapper can be set to three different options:

- OFF (shows the 10bit ADC value: 0-1023)
- *MAP*
- *NTC*



Figure 88: NTC

If set to OFF, no characteristic curve is activated and a value of 0-1023 is output.

If set to *MAP*, the values for zero and five volts can be entered. If the data sheet of your sensor only provides values for 0.5 and 4.5 volts, you can open the calculation tool by clicking on *calculate* to calculate the corresponding values for zero and five volts.

If set to NTC, you can enter the three constants of your NTC sensor as well as the pull-up resistance. If you only have three data points, the calculation tool will help you with one click on *calculate*.

While you're at it, you can directly assign the min and max values of your sensor 0

If the value of your *analog input* fidgets too much, you have the option of activating the attenuation. In the case of the *analog inputs*, this is hidden behind the point *Length*.



Figure 89: Attenuation of an analog input

If a 0 is entered here, the value is not damped. The maximum attenuation has a value of 249. A good starting value for damping is 210.

After you have adjusted all values, you can save your changes by clicking on Apply and then transfer them to your data display with the *export to display* button.

11 FAQ

This chapter collects recurring questions and offers solutions.

11.1 TRI/TRX file problem

If your data display shows you this error message, you have not selected a TRI/TRX file.



Figure 90: TRI/TRX file problem

Solution: Select TRI/TRX File as described in Chapter 6.3

11.2 Display does not turn on

If your display doesn't turn on, there's probably a problem with the power supply. In the first step, you can see if it starts when you connect it via USB. With the 5V from the USB your display should start, and you have to check your 12V wiring in the vehicle again.

If you look at the housing at the back of the display between the plugs, you will see a green LED light, which is activated by power supply (12V or 5V).

If the display does not start via USB, it must be sent in for further diagnosis by our service. Please contact <u>info@canchecked.de</u> by email before submitting to describe your problem and discuss further steps.

11.3 Display remains black or white

If your display is suddenly only black or white and no longer starts as usual, please carry out a software update as described in chapter 8. You can find the latest firmware in the download area of our website. Please flash the file named "init_gen2.1_customer_flash-erase.hex" first. Then you can follow the commands on your data display. Please select the appropriate firmware for your protocol (compare chapter 6.2). If there is no improvement, please contact info@canchecked.de with a complete description of the error.

11.4 I don't get any data (no can)

If your data display shows you under *Setup > Can Bus* in the upper right corner in red *no Can*6.26 and Can Low on pin 14. With a continuity tester, the passage can be checked from the OBD connector to plug B and a fault at this point can be diagnosed or ruled out.

For vehicles where the data display is connected directly to the Can Bus, the Can termination (2x120 Ohm resistors, alternatively activation/deactivation of the ECU internal resistors) and the correct connection must be checked.

Rev 1.2

If no improvement occurs, please contact <u>info@canchecked.de</u> with a complete description of the error.

11.5 Gear indicator does not work

The gear indicator calculates the gear from engine speed and speed. If your gear indicator does not work, this can have various causes:

- The sensors RPM, Speed and Gear are incorrectly assigned in the sensor init5.3
- Under Setup -> *Gears*5.5
- The widget itself is created incorrectly -> delete via DSS9

11.6 Yellow bar at the bottom of the data display

If images are missing on a page that are created in the layout of the page but are not stored in the flash memory, a yellow bar appears in the lower area and indicates the file is not found.



Figure 91: yellow bar

The error can be done by deleting the missing image from the page layout or by adding the missing image to the flash memory. The process for adding internal *DSS* images is described in Chapter 9.6

11.7 My Performance Meter runs permanently

If the *Performance Meter* runs continuously, even when stationary, the *widget* is assigned the wrong *sensor*. To assign the right *sensor* there are 2 ways:

unlocking the pages, click *performance meter*, assigning the *sensor* speed, locking the pages.

or

On the computer: Connect to the DSS, select the performance meter, assign the sensor speed.

11.8 My shift flash doesn't work

If the external switching flash does not work, there can be several reasons:

Please check whether plausible speed thresholds are stored for the individual LEDs under *Setup -> Shiftlight*.

Please check whether the sensor RPM is assigned appropriately under Setup -> 5.3

If both are correct, only the following remains to be checked: When starting the data display, the switching flash should run once. If this is not the case, the cabling must be checked.

11.9 How do I change my home logo?

It is possible to change the start animation or the start image. The animation consists of 20 images that are played one after the other. The files with the names *logo00*.bmp *to logo19.bmp* are located in the *pic* folder.

You have two options for changing, but no matter which one you choose, you have to convert your desired start animation/video into many small .bmp with a size of 320x240 pixels each or only provide one image with the appropriate size. If you upload only one image you only have one start image, if you upload several images, you have an animation in which the images run away one after the other:

• Manually remove the SD card, delete the 20 files and add the newly created images back to the folder

• From the *upload* section in the *DSS*, press remove all *logo*.bmp files from SD* to delete all logos and upload the newly created images with the name logo00.*bmp* using the *choose file* button



Figure 92: Buttons in the upload section

Once you have transferred all images to your data display, you must then press the erase flash button on the data display *under Setup -> Sensor Init -> erase flash or* in the upload section to delete the flash memory.

11.10 How to get other logos on the pages

Adding your own images and logos is done via the *upload* section in the DSS (chapter 9.6).

Before uploading, the images must be scaled to the appropriate size using a suitable program.

11.11 How do I rotate the UI of my display?

The user interface of your data display can be changed either on the display directly under Setup -> *Pages -> Orientation* or via the *DSS* (chapter 9.5.1).

11.12 My DSS gets stuck on page X

If your data display always gets stuck on a defined page when connecting, there may be two reasons for this.

Reason 1 on a Mac: The DSS was not moved to the application folder. Please copy the DSS to the application folder.

Reason 2: The page is damaged. The easiest way is to delete this page manually on the display and then create a new one.

To delete the page, please navigate to *Setup -> Pages* and enable and disable the page where it always hangs a few times. Then you will see the message deleted next to the *page*. Now the connection to the *DSS* should be done without any problems.

11.13 How can I find the cached images of the DSS

Windows: C:\Benutzer\[username]\AppData\Local\CANchecked-DSS\User Data \default\DSSdata

Mac: Macintosh HD>users>[username]>Library>Application Support>CANchecked-DSS>Default>DSSdata

11.14 How can I fine-tune a Can Bus sensor

The speedometer in your vehicle shows you a speed of 100 km/h, but on your display, it only shows 95 km/h. On the display we show you the true value and not an embellished value (the same applies to the coolant temperature). We show you the true value on the display and not an embellished value (the same applies to the coolant temperature).

If you want your display to show the same value as your speedometer, you can use the multiplier (see chapter 6). If you want your display to show 100 km/h instead of 95 km/h you must adjust the multiplier to 1.053 (100/95).

 $\frac{Value \ should}{Value \ is} = Multiplication \ factor$

The same applies to Can Bus sensors such as power or torque.

11.15 I can no longer edit the sensors on the display

Since firmware version 4.006, editing the sensors on the display is blocked by default. To unlock the pages, please unlock the corresponding page as described in chapter 5.10.

11.16 No connection with diagnostic tester possible

On some vehicles (especially BMW), no diagnostic connection is possible via the OBD socket when the display is active. To enable the OBD socket for diagnostics, the protocol must be deactivated or the OBD port must be unlocked. This process is described in chapter 5.2.5.

11.17 MicroSD card content and recovery

There are five folders on the microSD card. If the card or the folders are empty, the display starts but does not show any data or available TRI/TRX files. The following figure shows the folder structure of the card.



Figure

Figure 93: Folder structure of the microSD card

The TRI/TRX files are stored in the can folder. The .cod files required for reading out the error memory in plain text are stored in the codes folder. The logs folder contains the logging files stored with the display. The pictures and logos are stored in the pic folder. All arrangements of the pages are stored in the folder widgets.

If you receive a compressed ZIP archive from our website or by e-mail, it is imperative that this archive is extracted before the display is used again. The microSD card may only contain these five folders; subfolders or superfolders are not permitted.

11.18 MaxxECU with PQ34/PQ35 drivetrain

If the MaxxECU is operated with a PQ34 or PQ35 vehicle, can bus identifiers will overlap. To avoid this, please load the S-MAXX720.TRI file from our website and set the following in the MaxxECU under "Can Settings":

Default CAN output protocol	?	MaxxECU Default v1.3		~]
CAN ID Offset	?	512 <mark></mark>		
Message rate	?	Default (10/50Hz)	\sim	